

## Assembly instruction for wheel bearing kits

Einbauhinweis für Radlagersätze  
Instrucciones de montaje de kit de rodamiento  
Instructions de montage pour kit roulement de roue  
Инструкция по установке подшипника ступицы  
Istruzioni di montaggio per kit cuscinetti ruota

**MEYLE no. 53-14 652 0002**

**Short no. MCX0567**

To fit/Passend für/Aptos para/Convient pour/для/Adatti per

**LAND ROVER**



**Installation by qualified personnel only.  
Car manufacturer's instructions to be  
observed closely.**

Einbau nur durch geschulte Fachkräfte. Hinweise der Fahrzeughersteller genau befolgen.

El montaje sólo debe realizarse por un técnico instruido. Siga exactamente las indicaciones del fabricante del vehículo.

Installation uniquement par main-d'oeuvre spécialisée. Suivre les indications du fabricant d'automobile pour l'installation.

Монтаж должны производить только обученные специалисты. Следует точно соблюдать инструкции завода-изготовителя автомобиля.

Montaggio solo da parte di meccanici specializzati. Sono da seguire esattamente le istruzioni fornite dal costruttore del veicolo.



